



# Honda 6 Speed Rebuilding Tips

**The Honda/Acura 6 Speed: How  
to disassemble and assemble  
quickly and efficiently**

**Presented by:  
Bill Brayton  
ATRA Senior Research  
Technician**



© 2015 ATRA All Rights Reserved





*Any Questions Or  
Comments  
Please Contact  
Lance Wiggins  
At ATRA  
lwiggins@atra.com*

## 6-speed applications

- 2011 – current  
Honda Odyssey



- 2013 – current  
Honda Accord







## 6-speed applications Acura

- 2011 to 2015 TL/TLX
- 2011 and 2015 RL/RLX
- 2013 to current RDX
- 2010 - 13 ZDX
- 2010 to current MDX
- 2014 to current RLX





## *Honda 6 Speed Rebuild Tips*

Remove The four end covers and the two shaft nuts. Note: The twelve point nut is left handed threads.

The washers have an "X" stamped on the top of the washer. The washers have a small press fit and will need to be pried off the shafts.



34mm 12 point left handed thread nut  
"Righty Loosy, Lefty Tighy"

42mm 6 point right handed thread  
"Righty Tighy, Lefty Loosy"






## Honda 6 Speed Rebuild Tips



Remove the MLP sensor, filler tube, speed sensors (2), cooler lines, trans temp sensor. If your not sure about locations or don't have a book. Take a picture!  
Remove the thirteen 10mm bolts and remove the solenoid body.



ON/Off  
solenoids



PWM  
Solenoids

2014 ATRA. All Rights Reserved. Printed in U.S.A.

RA All Rights Reserved










## Line Pressure Solenoid "On"







## *Honda 6 Speed Rebuild Tips*

It may take a bit of a careful pry to get the solenoid body separated from the case. There are 11 feed pipes with O-rings between the solenoid body and the inner valve body.



All the tubes have filters in the end that goes into the Solenoid body. All need to be cleaned and inspected for debris

Remove the main case to bellhousing bolts. Sixteen 12mm bolts and fourteen 14mm bolts.







## *Honda 6 Speed Rebuild Tips*



Spread the snap ring and separate the main case from the bellhousing.



Be very careful with this spacer. It may stick to the case and fall on the floor and the tech would never know it was there.



2014 ATRA. All Rights Reserved. Printed in U.S.A.

RA All Rights Reserved





## *Honda 6 Speed Rebuild Tips*

Remove and discard the filter and remove the feed pipe.



Filter Bolt  
Best to use a deep  
1/4 inch drive  
10mm socket here

Feed Pipe

Filter Bolt

To get the lube dam out of the way the reverse gear, selector lever and slider **must** be removed.



2014 ATRA. All Rights Reserved. Printed in U.S.A.

RA All Rights Reserved





## ***Honda 6 Speed Rebuild Tips***



Remove the retaining bolt from the fork. Remove the fork and the selector gear.


**Note:** The ID ring on the selector gear faces down.

Groove faces  
down



Remove the lube feed pipe and 3 bolts to remove the lube dam.

Dam  
Bolts



Feed  
Pipe

Dam  
Bolts

2014 ATRA. All Rights Reserved. Printed in U.S.A.

RA All Rights Reserved





## ***Honda 6 Speed Rebuild Tips***



Remove the retaining bolt from the fork. Remove the fork and the selector gear.


**Note:** The ID ring on the selector gear faces down.

Groove faces  
down



Remove the lube feed pipe and 3 bolts to remove the lube dam.

Dam  
Bolts



Feed  
Pipe

Dam  
Bolts

2014 ATRA. All Rights Reserved. Printed in U.S.A.

RA All Rights Reserved





## ***Honda 6 Speed Rebuild Tips***

Remove the allen head bolts that keep the bearings on the Secondary and Counter Shafts. The larger allen head bolt is 12mm and has left handed threads. The smaller allen is 8mm and has right handed threads



The counter shaft bolt has an arrow showing that the bolt has left handed threads

Remove the secondary shaft bearing.







## ***Honda 6 Speed Rebuild Tips***

Remove the allen head bolts that keep the bearings on the Secondary and Counter Shafts. The larger allen head bolt is 12mm and has left handed threads. The smaller allen is 8mm and has right handed threads



The counter shaft bolt has an arrow showing that the bolt has left handed threads

Remove the secondary shaft bearing.







## ***Honda 6 Speed Rebuild Tips***



Use a proper puller to remove the counter shaft bearing. **DO NOT** pull on the gear to get the bearing off. This can chip the teeth of the gear.



Wrong Way



Right way

The lower race will stay on the counter shaft. Use a proper puller to remove the race from the counter shaft.



2014 ATRA. All Rights Reserved. Printed in U.S.A.

RA All Rights Reserved





## *Honda 6 Speed Rebuild Tips*



Remove the third shaft.



Remove the 2nd & 5th drum from the secondary shaft.



2014 ATRA. All Rights Reserved. Printed in U.S.A.

RA All Rights Reserved





## *Honda 6 Speed Rebuild Tips*

Remove the feed pipes.




Remove the idler gear.



2014 ATRA. All Rights Reserved. Printed in U.S.A.


RA All Rights Reserved





## *Honda 6 Speed Rebuild Tips*

Remove the differential and the transfer shaft.



Always replace the O-rings on the sleeve in the third shaft.







## ***Honda 6 Speed Rebuild Tips***



Remove the spacer washer and sleeve from the counter shaft. This step makes pulling the shaft up easier.



Remove the counter shaft and the secondary shaft.



2014 ATRA. All Rights Reserved. Printed in U.S.A.

RA All Rights Reserved





## ***Honda 6 Speed Rebuild Tips***



It is extremely important to have a stout puller set up to get this bearing out of the case. Its a very tight fit!

The collar under sleeve that has three O-rings that need to be changed on every build.

If the O-rings are not changed it can lead to a slips on take off complaint. This collar feeds the first clutch.

This puller is a Toyota factory tool for removing oil seals. OTC#09308-10010.



2014 ATRA. All Rights Reserved. Printed in U.S.A.


RA All Rights Reserved





## *Honda 6 Speed Rebuild Tips*

It is important to line the collar up correctly for installation. The tab on the collar goes into the slot in the case



### **CAUTION!**

It is easy to damage the sleeve when removing it from the case. Don't worry, they're cheap. Honda part# 23236-RT4-010. Last check on line 22 dollars and change





## *Honda 6 Speed Rebuild Tips*



The sleeve where the input shaft sealing rings ride is now a separate piece. This also support the stator tube that now has two O-rings instead of one as in years past.




2014 ATRA. All Rights Reserved. Printed in U.S.A.

RA All Rights Reserved






**Remove (2) two 12 mm bolts to remove the park pawl assembly.**







**Use a hooked scribe to remove the detent spring from the detent arm and  
Remove the detent arm and pivot post.**








**Twist the manual lever counter clockwise to disengage it from the manual valve.**


It is not necessary to disassemble the manual lever unless there are broken parts







**Remove the manual lever body  
and separator plate**




**Remove the  
(2) two  
check balls**







Remove the pressure regulator body and then finally the main control valvebody.







**Here is a link to the complete video  
presentation of disassembling the  
Honda/Acura 6 Speed transmission**

**<https://vimeo.com/111879078>**





# **Thank You for Attending Today's Presentation!**